



## **FIRE.IT Desktop Hub Installation Manual**

#### **Box Contents**

- (1) 5v USB Power Supply
- (2) USB Cable
- (3) Desktop Hub

# **Specifications**

## Environmental

Location

Outdoor or Indoor Use

# Dimensions and Weights (net)

	Height	Length	Depth	
Module	1 <sup>3</sup> / <sub>16</sub> '' (3 cm)	4 <sup>21</sup> / <sub>64</sub> '' (11 cm)	4 <sup>21</sup> / <sub>64</sub> '' (11 cm)	
Shipping	1 <sup>1</sup> / <sub>2</sub> '' (3.8 cm)	6 <sup>19</sup> / <sub>64</sub> '' (16 cm)	4 <sup>59</sup> / <sub>64</sub> '' (12.5 cm)	

#### Power

**Power Supply** 

5v 1amp

#### **Features**

- Control your firepalce from anywhere using WiFi
- Bluetooth only mode available
- Works with Alexa and Google Home
- Set up Weather Alerts
- Calibrate your firepalce so you can control by percentage
- Sun Tracker control
- Schedules and timers
- Bluetooth music feature
- Indicator light status

## Installing the Desktop Hub onto your Fireplace

- 1. Plug the Desktop Hub into power using the 5v USB power supply.
- 2. The Desktop Hub will flash red.
- 3. Download the FIRE.IT app from the Apple or Google Play Store.
- 4. Create an account.
- 5. Add the Desktop Hub on to the app. (Follow the app instructions).
- 6. Once successfully connected the Desktop Hub will light up a solid blue, indication it is connected to the internet.
- 7. Pair your remote control to the Desktop Hub.
- 8. You will now be able to control your firepalce from your smart device.

## Warranty